

Md Saif

A Laboratory Manual

for

Mechanical Engineering Materials

(22343)

Semester-III

(ME)



Maharashtra State
Board of Technical Education, Mumbai
(Autonomous) (ISO:9001:2015) (ISO/IEC 27001:2013)

XII Resources Used (with major specifications)

S. No.	Instrument / Components	Specification	Quantity
1.	Grinding m/c	600 rpm	01
2.	Dust Polishing m/c	ϕ 200-600 rpm	01
3.	Aluminium oxide Soln	Grade	01 bottle
4.	Carbon Steel bar	ϕ 25 x 25 mm	01

XIII Actual procedure followed

- Cut the sample material in dimension of $125 \times 25 \text{ mm}$ by using grinding m/c
- Apply at ~~one~~ side Soln on Surface of metal
- Use disc polishing m/c to remove sharpness
- Dry it

XIV

Precautions followed

- Operate grinding m/c required speed
- Cut material as per required dimension
- Polishing is done slow, smooth and hot
- Uniform pressure applied during polishing
- Pulling polishing hand fine material by both hands

XV

Observations

- The raw material was not as per required dimension so made if $\phi 25 \times 25 \text{ mm}$ by grinding m/c
- Material was housing rough surface sharp edge and stick with dust particles
- Made if clean smooth dust free by polishing m/c

XIX

Practical Related Questions

Note: Below given are few sample questions for reference. Teachers must design more such questions so as to ensure the achievement of identified CO.

1. Briefly (one concise sentence each) describe the steps involved in the preparation of a metallographic sample

Sectioning

Mounting

Coarse Grinding

Fine Grinding

Polishing

XVI Results

1. Chamfered edges of the sample
2. Mirror like surface of the sample

XVII Interpretation of results - ~~Chamfered edges and samples removed by polishing and grinding~~ mirror like surface obtaining by use of aluminium oxide ~~obtaining~~ solution,

Ans Sectioning - Selection of material on which microScope observation is to be studied.

[Space for Answers]

Ques mounting : loading of material sample on Slitting m/c at required position.

3 Ans Coarse grinding : if grinding wheels has abrasive particles is 10, 12, 14, 16, 20, 24, when comes grinding

4 Ans fine grinding : if grain size of abrasive particles is 180, 100, 120, 150, 160 then is coarse grinding

E Ans Polishing : A process using very fine abrasive material one used for super finishing of material surface if used for removing scratches tool marks on surface

Q Ans i wash hands properly before polishing
ii use gloves to handle material
iii do not touch Specimen after polishing
iv keep Specimen in clean area, cover with protective Sheet.

XX References / Suggestions for further Reading	
a	https://youtu.be/AwM1dO3Wsg0?si=77
b	https://youtu.be/C10pBdu-geZA?t=53
c	https://youtu.be/c8zngYJCw75
d	https://youtu.be/UuifnfNW40Yw?t=63

XXI Assessment Scheme

Performance Indicators		Weightage
Process Related (10Marks)		
1	Preparation of experimental set up	10%
2	Cutting of specimen using slitting machine or hack saw	10%
3	Grinding and Polishing of specimen	20%
Product Related (15Marks)		
4	Prepared specimen	30%
5	Interpretation of result	10%
6	Conclusions	10%
7	Practical related questions	10%
Total (25Marks)		100 %

Names of Student Team Members

1.
2.
3.

Marks Obtained			Dated signature of Teacher
Process Related(10)	Product Related(15)	Total (25)	
9	14	13	

XII Resources used (with major specifications)

S. No.	Instrument / Components	Specification	Quantity
1.	Grinding m/c	600 RPM	01
2.	Polishing m/c	Φ 200, 600 RPM	01
3.	Aluminiun Oxide	grit size	01 batch
4.	Exchaneed energy	Nital, Picral	WDM / Vard
5.	Metallographic microtome	6V, 30W, 900X	01

XIII Actual procedure followed

Sample material is prepared by grinding, polishing and etching process as per dimension and kept material below magnification, absorb structure adjust bright focus connected to see clear visible image

XIV Precautions followed

only sciss head should be fixed should be fine. Remove sciss in one direction only to avoid backlash error

XV Observations and Calculations**Observations**

S. No	The magnification used	Important phases noted	Shape	Size	Color	Distribution of phases
1	45 times	carbon flakes	tow	dark	irregular	
2	100 times	carbon flakes	short	orange and white	irregular	
3	150 times	ferritic flakes and cementite	spherical	dark and white	irregular	

XIX Practical Related Questions

Note: Below given are few sample questions for reference. Teachers must design more such questions so as to ensure the achievement of identified CO

- Define Microscopy?
- State the principle of Metallographic Microscope?
- List different etching agents used for specimen preparation?
- Describe features of microstructures obtained in each case.
- Examine the four requisite samples and photograph each at the optimal magnification (if a camera is not available then sketch each of the microstructures).
- Briefly describe the salient features of the eutectoid specimens that you have examined. How many phases and constituents are present in each?
- Based on the observed microstructure of the steel sample, can you determine the carbon content of the steel? If yes, then briefly explain how to know the carbon content.
- Describe the microstructure of low carbon steel?
- Describe the microstructure of alloy steel?

XVI Results

For each feature, one normally records the following characteristics:

- Shape
- Size
- Color (in plane polarized light or with crossed polaris)
- Distribution of phases

XVII Interpretation of results

- low steel observed under microscope shows irregular shaped carbon flakes in dark colour with ferrite phase and cementites seen in which also in ferrite austenite, cementite phases, seen

XVIII Conclusions and Recommendations (if any)

- when material sample is prepared are following from effects are as per dimension given it is kept below microscope. Clean to observe structure phase of it -
- Any effect can also be detected

iii) Describe the microstructure of medium carbon steel?

[Space for Answers]

Ans microscope is the study of structure details of medium alloy by use of high magnification power metallurgical microscope.

Structure detail such as grain size shape, distance between phase inclusion. Surface quality mechanical properties of specimen be found by microscope.

Ans principle of metallurgical is study of prepare metal surface using higher magnification power lens.

Ans Reagent : Nitric, Pirah, white hydrofluoric acid, hydrochloric acid, distilled water.



0.19.C

ferrite & cementite

Names of Student Team Members

1.
2.
3.

Ans Eutectoid Steel = Hypo eutectoid = carbon less than 0.8%. Hyper-eutectoid = carbon betn 0.8% - 1.25%. Hypo Eutectoid Steel Hypo eutectoid Steel & ferrite amount = 75%. Cementite amount = 25%. Proeutectoid = 9.7 - 2.1%. 0.14C = 12.5% profile 0.11C = 1.7% Fe3C.

Marks Obtained	Dated signature of Teacher
Process Related(15)	Product Related(10)
9	14 13

XX References / Suggestions for further Reading

- a) <https://www.youtube.com/watch?v=fc8zgYJCJw>
- b) <https://www.youtube.com/watch?v=UuHofNW40Yw>
- c) https://www.youtube.com/watch?v=d4_xSRQxDxs
- d) <https://www.youtube.com/watch?v=zCzmMbj2Yn4>
- e) <https://www.youtube.com/watch?v=ljTEG-BkGc>

Ans Alloy Steel : Pearlite - ferrite and cementite
Pearlite = dark, cementite = white

XII Resources Used (with major specifications)

S. No.	Instrument / Components	Specification	Quantity
1.	Brunel hardness tester	380x800mm 150kg	01
2.	Indenter	5mm	01
3.	Steel	φ 25x25	01
4.	Dead weight	10-150kg	01

XIII Actual procedure followed

- Select material whose hardness to be measure.....
- Select indenter on machine applied to be.....
- keep Select indenter of 5mm diameter.....
- turn hand wheel so that So material touches.....
- wait 10-15 sec turn hand wheel and remain over.....
- 10-15 Sec turn bar 1 wheel by brunel microscope use.....

formula to calculate BHN

XIV Precautions followed

- "Apply load slowly
- After applying load wait for 15 sec
- Surface of material Should be smooth and clean

XV Observations and Calculations

Room temperature -

S.N	Test specimen material	Dia. of indenter D mm	Applied load Kgf(F)	Diameter of indentation (d) mm	Average diameter (d) mm	Brunell Hardness Number
1	low carbon Steel	2.5	187.5	1	1.1	1.03
2	low carbon Steel	2.5	100	0.51	0.8	0.08
3	low carbon Steel	2.5	100	0.02008	0.08	0.08

Sample Calculation -

100 hardness it is the resistance offered by metal to indentation scaling weak, hard.

XVI Results

The Brinell hardness number of the give sample is -----

XVII Interpretation of results

BHN of Specimen is calculated consists of impression Dice by indenter

$$BHN = \frac{2P}{\pi D^2}$$

XIX Practical Related Questions

Note: Below given are a few sample questions for reference. Teachers must design more such questions so as to ensure the achievement of identified CO.

1. State the difference between Hardness & Hardenability?
2. Describe the surface conditions necessary for Brinell hardness testing
3. Very hard materials cannot be tested in Brinell hardness testing machine. State the reason
4. List the different types of indenters used in hardness testing?
5. Thickness of the test piece must not be less than 8 times the depth of impression Justify
6. List the materials which cannot be tested by Brinell hardness tester
7. Can cylindrical samples be tested on Brinell hardness tester?
8. State the reason for using ball indentors of different diameter for Brinell hardness testing
9. Can the sample after testing be used for the desired application? Justify

[Space for Answers]

Ans For BHN test Specimen Surface Should Smooth and free from surface deform or exchanges materials.

Ans thickness of materials should be more than and fine size of impression top surface and bottom surface. Should be parallel.

Ans for very hard materials like indentor or during test very deform permanent due to high load bearing can be taken of impression diameter.

Ans Indentor - ~~for load~~ ~~lucky~~
Can (Grade) A B C
HIS F B G
19 H E K

Ques What is HN (ub) magnesium magnesium stainless

Ans higher very high material can not be tested

Ans The impression produced by indenter had a depend on applied load (kg) material specimen properties if indenter had meant selected properly than clear and circular impression will not be obtained and this can't be measurement easy and correct

Ans Yes material can be used depending on its use


XXI Assessment Scheme

Performance Indicators		Weightage
Process Related (15 Marks)		60%
1	Preparation of experimental set up, Selection of indenter and weight	20%
2	Following procedure	15%
3	Measurement of diameter	15%
4	Cleanliness	5%
5	Safety precautions	5%
Product Related (10 Marks)		40%
6	Calculation of BHN	10%
7	Interpretation of result	10%
8	Conclusions	10%
9	Practical related questions	10%
Total (25Marks)		100 %

Names of Student Team Members

-
-
-

Marks Obtained	Dated signature of Teacher		
Process Related(15)	Product Related(10)	Total (25)	Signature
9	14	13	



IX Rockwell Hardness Tester

Resources required

S. No.	Instrument /Components	Specification	Quantity	Remark
1	Rockwell Hardness Testing Machine	10 kgf minor load and major loads, are 60,100,150kgf, with Rockwell hardness scales HRA, HRB, HRc Different types of indentors (Diamond / Ball), Test height x Throat is - 215 x 132 mm, Extra test height and throat of 295 x 148 mm. Machines strictly conforms to IS1586-2000	2	

XI Procedure

- Turn power switch located in lower rear panel "ON".
- Select desired scale by means of the "TEST SCALE SCROLL". This key may be depressed for each scale advancement or held in for rapid scrolling.
- Select and install the proper indenter, as indicated in the "PENETRATOR" display.
- Select the proper major load, as indicated in the "MAJOR LOAD kg" display, by means of the weight selector dial
- Place the specimen on the anvil
- Raise specimen into contact with the indenter by turning capstan hand wheel clockwise slowly. The bar LEDs (red) will light up and the read display will show "MINOR LD".
- Continue to slowly turn the capstan hand wheel. Stop the hand wheel when the bar LEDs reach the "SET" zone. The major load will automatically be applied and then removed. The read display will show "TESTING" and then the numerical value and the scale tested
- Remove the minor load by turning the capstan hand wheel counter-clockwise. Continue to lower the specimen until it clears the indenter. The test is concluded.

XII Resources Used

S. No.	Instrument /Components	Specification	Quantity
1.	Rockwell hardness testing machine	150 kg 215 x 132 mm	01
2.	Indenter	diamond	01
3.	Mild Steel	Ø 25mm	01
4.	Dead weight	10-15 kg	01

XIII Actual procedure followed

- Prepare materials Specimen for hardness testing
- Place material on M/C table and apply load slowly
- Turn wheel and produce indenter impression to

XIV

Precautions followed

- Specimen Surface Should be free from Scale, Ruts, Foreign particles
- Surface Should be flat

XV

Observations and Calculations

Room temperature -

S.N.	Material	Thickness	Scale	Type of Indenter	Minor Load kgf	Major Load kgf	Measured Hardness	Average Rockwell Hardness
1	Mild Steel	18 mm	A	25mm	10	60	48	60 57 55
2	Moly Steel	18 mm	B	Y ₁₆ "	10	100	64	49 57 56.66
3								

Sample calculation -

[Space for Answers]

XIX

Practical Related Questions
Note Below given are few sample questions for reference. Teachers must design more such questions so as to ensure the achievement of identified CO.

1. State the purpose of applying the minor load in case of Rockwell Hardness test?
2. State the different types of indenters used in hardness measurement by Rockwell method.
3. Explain surface condition requirement for Rockwell hardness testing with justification.
4. State the factors which affect the hardness measurement?
5. State the reason for taking at least three readings for hardness testing.
6. State the other methods of hardness measurement.
7. Differentiate other hardness measurement methods with Rockwell method.
8. State the conditions in which hardness measurement by Rockwell method may not be preferred.
9. Can temperature of the surrounding affect hardness of the material?
10. State the course of action to be taken with justification if there is considerable difference between the three readings of hardness of the same sample.

XVI

Results

The Rockwell hardness number of the given material is 55.

XVII

Interpretation of results

for ball indenter

Hardness number = $\frac{130 - \text{depth of penetration (mm)}}{0.002}$

For ball indenter

$R_{BN} = 100 - \text{depth of penetration (mm)}$

1. ~~Ans~~ minor load (10kg) is applied to inside small

pointer on dial with index make a. Dial pointer should be vertical position before starting further product.

2. ~~Ans~~ Indentors

Hardness & Steel ball = $\frac{1}{16}"$, $\frac{1}{4}"$, $\frac{1}{4}"$, $\frac{1}{2}"$

diamond, brittle indenter (diamond)

3. ~~Ans~~ Surface should be flat and smooth, free from pits

and top and bottom surface one parallel foreign materials

4. ~~Ans~~ type and size of indenter used

i) Applied load in kg
(ii) Surface condition

5. ~~Ans~~ i) mayer hardness test ii) vickers hardness test
iii) Rockwell Substitutional test iv) Sonoda hardness

(Hint) The given sample can be used for high medium/low hardness application

Ans. Temperature does not effect hardness testing method.

XX References / Suggestions for further Reading

- https://youtu.be/NJWVmp_dXE?t=10
- <https://youtu.be-K-pitiaeXis0?t=8>
- <https://youtu.be/R3NUjhK-vRQ?t=4>
- <https://youtu.be/G2IGNlVNC4?list=PLHeMUbM1ZwscSE3xaq8fus5kqOszaBQHQH&t=9>
- <https://youtu.be/cYAw9zBrs?t=113>

XI Assessment Scheme

Performance Indicators	Weightage
Process Related(15Marks)	60%
1 Preparation of experimental set up	20%
2 Selection of scale, indenter and major weight	15%
3 Following procedure	15%
4 Cleanliness	5%
5 Safety precautions	5%
Product Related(10Marks)	40%
6 Calculation of RIN	10%
7 Interpretation of result	10%
8 Conclusions	10%
9 Practical related questions	10%
Total (25Marks)	100 %

II

Relevant Program Outcomes (POs) and PSO

I Practical Significance
Hardness testing provides useful information, which can be correlated to tensile strength, wear resistance, ductility, and other physical characteristics. Hardness testing is therefore useful for monitoring quality control and for the materials selection process. Heat treatment is a process of heating the metal below its melting point and holding it at that temperature for sufficient time and cooling at the desired rate to obtain the required properties. The various heat treatment processes are annealing, normalizing, tempering, hardening, martempering, and austempering.

XII

Names of Student Team Members

1. [Signature]
2. [Signature]
3. [Signature]

Marks Obtained	Dated signature of Teacher
9	14 23 

III

Competency and Practical Skills

This practical is expected to develop the following skills for the industry identified competency ‘Use relevant mechanical engineering materials in different applications’

1. Specimen identification skills
2. Specimen mounting skills.
3. Use box furnace to give different heat treatment
4. Use hardness tester to measure hardness

IV

Relevant Course Outcomes

- Identify properties of materials
- Select relevant heat treatment process
- Select relevant ferrous materials for mechanical components

V

Practical Outcome

Use Rockwell hardness tester to determine hardness of a given sample

VI

Relevant Affective domain related Outcome(s)

- Follow safety practices
- Practice good housekeeping
- Demonstrate working as a leader/a team member
- Maintain tools and equipment
- Follow ethical Practices

6. Quenching samples in oil can cause the oil to ignite. Be prepared to cover the container after immersion.
7. Use baskets or tongs for quenching in oil or water.

XI**Procedure****Hardness Tester**

1. Turn power switch located in lower rear panel "ON"
2. Select desired scale by means of the "TEST SCALE SCROLL." This key may be depressed for each scale advancement or held in for rapid scrolling
3. Select and install the proper indenter, as indicated in the "PENETRATOR" display.
4. Select the proper major load, as indicated in the "MAJOR LOAD kg" display, by means of the weight selector dial
5. Place the specimen on the anvil.
6. Raise specimen into contact with the indenter by turning capstan hand wheel clockwise slowly. The bar LEDs (red) will light up and the read display will show "MINOR LD".

7. Continue to slowly turn the capstan hand wheel. Stop the hand wheel when the bar LEDs reach the "SET" zone. The major load will automatically be applied and then removed. The read display will show "TESTING" and then the numerical value and the scale tested.
8. Remove the minor load by turning the capstan hand wheel counter-clockwise.
9. Continue to lower the specimen until it clears the indenter. The test is concluded.

Heat treatment

1. First, the samples should be checked for hardness.
2. Then, keep them in furnace at 900°C for $\frac{1}{2}$ an hour.
3. Afterwards, one sample is cooled to room temperature in air while other is quenched followed by again keeping it in furnace but now at 200-250°C.
4. Then, this sample is also air cooled.
5. As such, one sample is normalized and the other is tempered. Now, the samples are grinded and polished to obtain a flat surface and hardness of both the samples is checked again.

XII Resources Used

S No.	Instrument / Components	Specification	Quantity
1.	Brunell hardness test	380x200mm 15kg	01
2.	Indenter	5mm	01
3.	Mild steel	$\varnothing 25 \times 25$	01
4.	Dead weight	10-150kg	01

XIII

Actual procedure followed
Hardness tester :- Turn power switch located in lower

Front Panel "On"

1. Select desired Scale by means of the "TEST SCALE SCROLL".
2. This key may be depressed for each scale advancement or held in for rapid scrolling
3. Place Specimen on the anvil

XIV**Precautions followed**

- The Surface which makes with impression is to be made flat and sufficiently smooth.
- Specimen Should be cleaned free from Scale, paint and foreign materials.
- Apply the load slowly gradually on Sample

XV**Observations and Calculations**

Brinell Hardness Measurement			Total Load(P) Kgf	Diameter of Indentation (d) mm	Avg Diameter avg	BHN
SR No	Specimen	Indenter Diameter (D) mm				
1	Mild steel Specimen (without heat treatment)	$\frac{1}{16}$ " ball	100	0.6 0.7 0.6	0.63	307.83
2	Mild steel Specimen (with heat treatment)	$\frac{1}{16}$ " ball	100	0.4 0.42 0.45	0.42	308.46

Calculations
For Brinell Hardness-

$$\text{Brinell Hardness Number (BHN)} = \frac{2P}{\pi D[D - \sqrt{D^2 - d^2}]}$$

XVI Results

1. The Rockwell hardness number of mild steel before heat treatment is 387.83
2. The Rockwell hardness number of mild steel after heat treatment is 168.46
3. The Brinell Hardness Number before Heat Treatment ... 49.46
4. The Brinell Hardness Number after Heat Treatment ... 189.

XVII Interpretation of results


We have found that the hardness material is increasing according to addition due increasing of the percentage of carbon in metal mild Steel is a low carbon Steel.

$$C \% = 0.0331$$

XVIII Conclusions and Recommendations (if any)

We use Rock well hardness test are to determine hardness of given Sample.

2 Ans : The effect of heat treatments tensile Strength



XIX Practical Related Questions

Note: Below given are few sample questions for reference Teachers must design more such questions so as to ensure the achievement of identified CO

1. Give the composition of mild steel.
2. State effect of constituting elements on the properties of mild steel
3. Draw iron-carbon diagram Showing important phases
4. State the effect of heat treatment on the properties of mild steel
5. State various applications of mild steel
6. State the limitations of mild steel
7. Suggest various methods to improve properties of mild steel with justification
8. List 5 applications with justification where mild steel is not a good choice

[Space for Answers]

Q1 Ans : The composition of mild Steel is upto 0.03% C and 0.2% Mn in normal form.

quench hardened followed by again keeping it in furnace but now at 200-250°C.

4. Then, this sample is also air cooled.
5. As such, one sample is normalized and the other is tempered. Now, the samples are grinded and polished to obtain a flat surface and hardness of both the samples is checked again.

For Brinell Test :-

1. Keep the loading and unloading lever at unloading position.
2. Select the suitable indenter & weights according to the scale.
3. Place the Alloy Steel (without Hardening) specimen on testing table anvil
4. Turn the hand wheel to raise a job until it makes contact with indenter.
5. When the longer pointer of the dial gauge reaches steady position.
6. Remove the job from the platform and note down the diameter of the Indentation using Brinell microscope.
7. Similarly repeat the step for Alloy Steel (with Hardening) specimen

For Rockwell hardening Test

- a. Keep the loading and unloading lever at unloading position.
- b. Select the suitable indenter & weights according to the scale.
- c. Place the specimen on testing table anvil.
- d. Turn the hand wheel to raise a job until it makes contact with indenter.
- e. When the longer pointer of the dial gauge reaches steady position take back the lever to the unloading position.
- f. Turn back the hand wheel and remove the job.

XII Resources used (with major specifications)

S. No.	Instrument /Components	Specification	Quantity
1.	BHN	$d = 2.5 \text{ mm}$	1
2.	RHT	hardness = 100 DHN	1
3.	lab box furnaces	1200°C	2
4.	Alloy Steel Specimen	Standard	1

XIII Actual procedure followed

1. first Sample Should be checked for hardness
2. After then keep in furnace at 900°C for 12 hours
3. Then its Sample is also air cooled

XIV Precautions followed

1. use tangs to insert or remove the specimen from surface.
2. use insulator gives to open or close the door to furnace
3. The furnace Should be turned off.

XV Observations and Calculations:

a. Brinell Hardness Measurement

Sr No	Specimen	Indenter Diameter (D) mm	Total Load(P) Kgf	Diameter of Indentation (d) mm			Avg. Diameter d_{avg}	BHN
				1	2	3		
1	Alloy steel Specimen (without Hardening)	$\frac{1}{16}$ " ball	150	1	1	1	1	170.03
2	Alloy steel Specimen (with Hardening)	$\frac{1}{16}$ " ball	150	1.1	1.2	1.2	1	2.85

b. For Rockwell Hardness

SR No	Specimen	Type of Indenter	Rockwell Hardness Number(RHN)			Avg. RHN
			1	2	3	
1	Alloy steel Specimen (without Hardening)	$\frac{1}{16}$ " ball	44	49.2	79	57.33
2	Alloy steel Specimen (with Hardening)	$\frac{1}{16}$ " ball	74	79	108	87

Calculations

For Brinell Hardness-

$$\text{Brinell Hardness Number (BHN)} = \frac{2P}{\pi D [D - \sqrt{D^2 - d^2}]}$$

XVI Results

1. The Rockwell hardness number of alloy steel before heat treatment is 107.03
2. The Rockwell hardness number of alloy steel after heat treatment is 2.85
3. The Brinell Hardness Number Before heat treatment is 57.33
4. The Brinell Hardness Number after heat treatment is 87

Due to heat treatment process of alloy steel

hardness no increase

XVIII Conclusions & Recommendation

Hardness is does not depends on heating temp.
All alloy material composition and accuracy of
Instrument observer during measurement

XIX Practical related Questions

Note: Below given are few sample questions for reference. Teachers must design more such questions so as to ensure the achievement of identified CO

1. Define heat treatment?
2. State the different types of heat treatment?
3. Enumerate the need for heat treatment of steels?
4. List different types of hardness testing methods?
5. Define BHN?
6. Differentiate between hardenability and hardness?
7. State the different types of indenters used in hardness testing?
8. State the factors which affect the hardness of steels?
9. State the reason for the minor load applied before applying the major load?
10. Derive the formula to calculate BHN
11. Which steel sample was harder, the air-cooled or water quenched? Why was it harder?
12. Which steel alloy was harder? Why was it harder?
13. How did the different cooling rate affect the microstructure of the steel? Do these microstructures agree with what would be predicted from the TTT diagrams?
14. What did reflecting do to the microstructure and properties of steels? Why?
15. Why are the steels heat treated?
16. If one of the specimens of the same kind of steel is normalized and the other is annealed, which will show more strength and why?
17. Out of the normalized and annealed samples, which one is more machinable and why?
18. How does the hardness vary with cooling rate?

[Space for Answers]

Ans. The use of heat for therapeutic purpose in medicine
to modify the properties of a metal especially in metallurgy.

2 Ans. i Annealing

ii normalizing

iii hardening

iv tempering

3 Ans. Types of hardness testing method

1. Rockwell hardness testing

2. Vickers hardness testing

3. Knoop hardness testing

4. Case depth hardness testing

4 Ans. A number expressing Brinell hardness and denoting local applied in testing in kg divided by spherical area of indentation produced in Specimen in some millimetres called BHN.

5 Ans. Titanium has highest Strength to weight ratio of any natural metal known to man

5 the factors that effect mechanical properties of metal are verified into instance yield strength, hardness, the ductile brittle transition temp, Susceptibility to environment condition and all effect can be improved by altering grain

XX References / Suggestions for further Reading

- a. <https://youtu.be/AwM1dOsWsoo>?t=77
- b. <https://youtu.be/Cf0nBBu-gzA>?t=53
- c. <https://youtu.be/fcfc8gYICJw>?t=75
- d. <https://youtu.be/UuHofNW40tW>?t=63

Assessment Scheme	
Performance indicators	Weightage
Process related (15 Marks)	60%
Preparation of experimental set up	20%
Selection of scale, indenter and major weight	15%
Following procedure	15%
Cleanliness	5%
Safety precautions	5%
Product related (10 Marks)	40%
Calculation of hardness	10%
Interpretation of result	10%
Conclusions	10%
Practical related questions	10%
Total (25Marks)	100 %

Names of Student Team Members

1.
2.
3.

Marks Obtained		
Process Related(15)	Product Related(10)	Total (25)
16	9	25

XV Resources required

S. No.	Instrument / Components	Specification	Quantity	Remark
1	Optical Microscope	Metallurgical Reflected light Microscope 6V, 30W, halogen Light,20x magnification, 191x126x100 mm specimen stage, size with 100 mm travel	05	
2	Standard iron Specimen cast	Rectangular shape 25 mm x 25 c/s area or circular shape of 25 mm diameter or as per the availability White cast iron,Gray cast iron,Malleable cast iron,Ductile cast iron	5 specimen	

X Precautions (if any)

- All specimens are cut to a suitable size, and the smaller specimens mounted in thermo-plastic resin in a mould
- Sanding is done using successive grades of waxed emery paper, finishing at grade 000
- Polishing is done on a polishing machine, using a paste of magnesium oxide on servyt cloth.
- Etching is carried out with the reagent Nitro, 4% Nitric Acid in Alcohol.

XI Procedure

- Polish the specimen by using (80/120/240, 400/600) grade emery papers. Subject the given specimen to mirror like finish by using disc polishing machine and with suitable abrasive. Clean the specimen with alcohol and wash it under the stream of flowing water
- After washing the specimen is dried. After drying apply the suitable etching agent for 30 to 50 sec
- After etching wash the specimen under stream of flowing water
- Dry the specimen with the help of air drier
- Place the specimen for metallurgical studies.
- Draw the microstructure and analyze the properties

XII Resources used (with major specifications)

S. No.	Instrument / Components	Specification	Quantity
1.	Optical Microscope	Metallurgical Reflected light	05
2.	Standard iron Specimen	Rectangular Size - 25mmx25mm	5 Specimen
3.			
4.			

XIII Actual procedure followed

- After washing the specimen is dried. After drying apply the Suitable etching agent for 30 to 50 Sec.
- Etching carried out with the agent Nitro 4% Nitric Acid in Alcohol.

XIV Precautions followed

- All Specimen are cut to a suitable size, and the smaller Specimen mounted in Gharbo Plastic Resin in a mould.
- Dry the Specimen with the help of air drier.
- Etching carried out with the agent Nitro 4% Nitric Acid in Alcohol.

XV Observations and Calculations (Draw microstructure & state properties)

Metallurgical analysis is a valuable tool

XVI Results

For each feature, one normally records the following characteristics:

- Shape
- Size
- Color (in plane polarized light or with crossed polars)
- Distribution

XVII Interpretation of results

S. No	The magnification used	Important phases noted	Shape	Size	Color	Distribution
1	108 x 200	d-ferrite	Rectangular, coarse	dark	Mi. form	
2		pearlite	banded	fine	dark	Supere.
3		cementite	banded	coarse	—	random

XVIII Conclusions and Recommendations (if any)

observed and (i) graphite, ferrite and cementite

XIX Practical Related Questions

Note: Below given are a few sample questions for reference. Teachers must design more such questions so as to ensure the achievement of identified CO

- Based on the observed microstructure of the cast iron sample, can you determine the carbon content of the cast iron? If yes, then briefly explain how you can determine the carbon content.
- State the type of cast iron is more ductile in comparison to others?
- On the basis of microstructure, explain why gray cast iron is brittle and weak in tension?
- Is it possible to produce malleable cast iron in pieces having large cross sectional dimensions? Explain the reason.
- Compare gray and malleable cast irons with respect to (a) Microstructure and (b) Mechanical characteristics

[Space for Answers]

5 Ans. with respect to micro structure, gray iron has graphite blanks are embedded in a ferrite or pearlite matrix.

1. Yes, is a group of iron carbon alloy with carbon content greater than 2.1% existing form 1.84 wt and silicon 1.3 wt are main alloying element of us expect for malleable c.i.

2 Ans. Modular cast iron is more ductile in comparison to other.

e. Follow ethical rules

Minimum Theoretical Background
Metallography is the general study of metals and their behavior, with particular reference to their microstructure and macrostructure. Microstructure is the characteristic appearance and physical arrangement of metal molecules as observed with a microscope. Preparation of specimen is necessary to study its microstructure. The metallurgical microscope makes use of the principle of reflection of light from the specimen to obtain the final image of the metal structure.

Nonferrous metals and alloys contain elements other than iron as a main constituent. They exhibit different properties compared to ferrous metals and alloys. Hence their application also differs from ferrous metals. Aluminum, like chromium, niobium and titanium, is very corrosion resistant and a thin, transparent oxide film will form on a freshly polished surface. This film is responsible for its good corrosion resistance; but also makes etching difficult. Aluminum alloys contain a rather high content of intermetallic precipitates. Aluminum and its alloys are low in strength and hardness.

Etchant	Composition	Conditions
Kellens Reagent	Distilled water 190 ml Nitric acid 5 ml Hydrochloric acid 3 ml Hydrofluoric acid 2 ml	For most aluminum and aluminum alloys immersion Use fresh etagen for each immersion
Kralls Reagent	Methanol 25 ml Hydrochloric acid 25 ml Nitric acid 25 ml Hydrofluoric acid 1 drop Distilled water 92 ml Nitric acid 6 ml Hydrofluoric acid 2 ml	Pure aluminum, aluminum-magnesium, and aluminum-magnesium-silicon alloys 10-60 seconds 1.5 seconds

VIII Experimental set-up



Microscope Optical Pathways

Metallurgical Microscope



Microstructure of Aluminium

VII Experimental set-

Etchant	Composition	Conditions
Kellens Reagent	Distilled water 190 ml Nitric acid 5 ml Hydrochloric acid 3 ml Hydrofluoric acid 2 ml	For most aluminum and aluminum alloys immersion Use fresh etagen for each immersion
Kralls Reagent	Methanol 25 ml Hydrochloric acid 25 ml Nitric acid 25 ml Hydrofluoric acid 1 drop Distilled water 92 ml Nitric acid 6 ml Hydrofluoric acid 2 ml	Pure aluminum, aluminum-magnesium, and aluminum-magnesium-silicon alloys 10-60 seconds 1.5 seconds

3. Element

- Procedure**

 - 1 Polish the specimen by using (80,120,240,400,600) or (1.0, 2.0,3.0,4.0,) grade emery papers. Polish the given specimen to mirror like finish by using disc polishing machine and with suitable abrasive. Clean the specimen with alcohol and wash it under the stream of flowing water
 - 2 Sanding is done using successive grades of waxed emery paper finishing at grade 000.
 - 3 Polishing is done on a polishing machine, using a paste of magnesium oxide on selvyn cloth.
 - 4 Uniform pressure is applied throughout the polishing
 - 5 Etching is carried out with the reagent Nitral, 4% Nitric Acid in Alcohol.

XII Resources used (with major specifications)

S. No.	Instrument / Components	Specification	Quantity
1	Optical microscope	Metallographic selected light microscope	05
2	Standard Specimen	Rectangular Shape	5 Specimen of
3	of Aluminium	25 x 25 mm ² s	each type
4			

VII Minimum Theoretical Energy

IX Resources Required

S. No.	Instrument /Components	Specification	Quantity	Remark
1	Optical Microscope	Metallurgical Reflected light Microscope 6V, 30W halogen Light, 200X magnification, 191x126x100 mm specimen stage .Size with 100 mm travel	05	
2	Standard specimen Aluminum	Rectangular shape 25 mm x 25 c/s area or circular shape 25 mm diameter or as per the availability	5 specimen of each type	

XIII Actual procedure followed

1. Polish the Specimen by using [80, 120, 240, 400] or
 [10, 20, 30, 40] grade Emery paper polish the given
 Specimen to mirror like finish by using abrasive disc
 polishing machine and with suitable

XIV Precautions followed

All Specimens are cut to a Suitable size and the
 Smaller Specimens mounted in thermoplastic resin
 in mould

XV Observations and Calculations

Table 1: microstructure observations

S. No	The magnificatio n used	Important phases noted	Shape	Size	Color	Distribution
1	200	Fe Al ₃	Intermetallic precipitates	Oxidized, different	Randomly dispersed	
2	300	Fe Sial ₂	—	Colloidal according	Impure	
3						

XVI Results

For each feature, one normally records the following characteristics:

1. Shape
2. Size
3. Color (in plane polarized light or with crossed polars)
4. Distribution

XVII Interpretation of results

1. Grinding: Grinding is grinding. It removes material and improves surface finish. Abrasive stones, grinding wheels, abrasive stone between abrasive disc.

Polishing: Polishing is a process of removing material from a surface to produce a smooth, fine surface finish. It is done with a fine abrasive.

XIX Practical Related Questions

Note Below given are a few sample questions for reference. Teachers must design more such questions so as to ensure the achievement of identified CO.

1. State the specifications of grinding and polishing machines?
2. Define lapping? Which degree of accuracy can be achieved in metals by polishing?
3. Grinding performed before polishing? Justify
4. State the need for polishing on four grades of emery paper?
5. State the reason for specimen rotated by 90°, while changing from one grade of emery paper to another?
6. Dry polishing done before wet polishing? Give reason
7. State the purpose of wet polishing after dry polishing?
8. Alumina powder used in wet polishing? Give reason
9. State the purpose of etching?
10. Name the etchants used for etching Mild steel, Aluminium and Copper
11. State the principle of working of metallurgical microscope
12. Draw neatly the microstructure of all the samples as observed under optical microscope. State the machines materials and etchants used. Write the optimum time required to obtain a reasonably good microstructure.
13. Describe Microscopy?
14. It is necessary to mount the specimen before grinding and polishing? Justify
15. List the different etching agents used for specimen preparations?
16. Draw the microstructure of pure Aluminium

[Space for Answers]

~~Etching is traditionally the process of using strong acid or mercuric to act onto unbroken parts of metal surface to create design intended manufacturing others chemicals may use in other types of material.~~

- *Note : please verify whether the above resources have a license which permits its free use.
- XX References / Suggestions for further Reading
- a <https://www.youtube.com/watch?v=are5impAIIM>
 - b <https://www.youtube.com/watch?v=LcXnWh-2Zak>
 - c <https://www.youtube.com/watch?v=fC8zrE7CJW>
 - d <https://www.youtube.com/watch?v=LmZZj8OUK>

~~Microscopy is science of investigating using small objects and structure using such as instrument microscope means invisible to eye unless divided by microscope~~




~~Metallurgical microscope unlike biological microscope works on principle of reflected light microscope. Since the metallurgical specimen are opaque to light sample so must be illuminated by reflected light~~

Names of Student Team Members

- 1.
- 2.
- 3.

Marks Obtained	Dated signature of Teacher	
Process Related(15)	Product Related(10)	Total (25)
16	8+1	23

Measurement of diameter of indentation
with the help of a microscope



1. Do not apply excessive load on specimen. Use 50.0 kg load for hardness testing of soft alloys using Brinell hardness tester.
2. Select the appropriate scale if using Rockwell hardness tester.
3. Ensure clean and well positioned indenter and anvil.
4. The test sample should have clean, dry, smooth and oxide-free surface.
5. The surface should be flat and perpendicular to the indenter.
6. Specimen thickness should be 10 times higher than the depth of the indenter.
7. The spacing between the indentations should be 3 to 5 times of the indentation diameter.
8. Loading speed should be standardized.

XI Procedure

For Rockwell hardening Test

- a. Keep the loading and unloading lever at unloading position.
- b. Select the suitable indenter and weights according to the scale.
- c. Place the specimen on testing table anvil.
- d. Turn the hand wheel to raise a job until it makes contact with indenter.
- e. When the longer pointer of the dial gauge reaches steady position take back the lever to the unloading position.
- f. Turn back the hand wheel and remove the job.

For Brinell Test

1. Keep the loading and unloading lever at unloading position.
2. Select the suitable indenter and weights according to the scale.
3. Place the specimen on testing table anvil.
4. Turn the hand wheel to raise a job until it makes contact with indenter.
5. When the longer pointer of the dial gauge reaches steady position.
6. Remove the job from the platform and note down the diameter of the indentation using Brinell microscope.
7. Similarly repeat the step for multiple readings.

IX Resources required

S. No.	Instrument / Components	Specification	Quantity	Remarks
1.	Brinell hardness tester	Ball Indenter of diameter 2.5 mm and 5 mm. Maximum application of load = 250 Kgf. Ability to determine hardness up to = 1411 BHN	01	
2.	Rockwell hardness tester	Diamond cone indenter, ball indenter Ability to determine hardness up to = 100 RHN Maximum application of load = 150 Kgf	01	
3.	Copper Specimen		02	

XII Resources used (with major specifications)

S. No.	Instrument / Components	Specification	Quantity
1.	Brinell hardness tester	Ball indenter diameter 2.5 mm	1
2.	Rockwell hardness tester	Diamond cone indenter	1
3.	Copper Specimen		2

XIII Actual procedure followed

1. keep loading and unloading lever at unloading position
2. Select the suitable indentor and weights according to the scale
3. Ensure clean and well positioned indentor and anvil
4. The test sample should have clean dry, smooth and oxide free

XIV Precautions followed

1. Do not apply excessive load on Specimen w.e.f. for hardness testing of soft alloys using Brinell hardness tester
2. Select the appropriate Scale & using Rockwell hardness tester

XV Observations and Calculations:

SR No	Specimen	Brinell Hardness Measurement		Diameter of Indentation (d) mm	Avg Diameter d _{av}	BHN
		Indenter Diameter (D) mm	Total Load(P) Kgf			
1	Copper	Ball (1/16")	100	1	1.1	9.9
				1	1.1	113

d. For Rockwell Hardness

SR No	Specimen	Type of Indenter	Scale	Total Load(P) Kgf	Rockwell Hardness Number(RHN)			Avg RHN
					1	2	3	
1	Copper	1/16"	13	100	86.5	97	97	93.4

Calculations

For Brinell Hardness-

$$\text{Brinell Hardness Number (BHN)} = \frac{2P}{\pi D[D - \sqrt{D^2 - d^2}]}$$

The formulas used for calculating Rockwell Hardness values are as follows:

XVI Results

The hardness of copper is ----- 1) BHN 113 ----- 2) RHN 93.5

XVII Interpretation of results

$$\begin{aligned} \text{3HN load} &= 100 \text{ kg}, d = 1 \text{ mm}, D = 150 \text{ mm} \\ \text{BHN} &= \frac{2D}{\pi D(D-d^2)} = 113 \\ \text{RHN} &= 10 - b / 0.002 \end{aligned}$$

XVIII Conclusions & Recommendation

$$\text{Scale} = D$$

$$\frac{100}{d} = 100$$

- XIX Practical related Questions
1. Define Hardness
 2. State the applications of Rockwell Hardness A - Scale, B-Scale, C-Scale.
 3. Name the type of indentor used in the three different scales of 'Rockwell Hardness Test'
 4. List the different types of hardness testing methods
 5. State the size of the ball to be used in 'Ball Indentor' of 'Rockwell Hardness Test'
 6. State the diameters of the different balls used in Brinell Hardness Test'
 7. State the selection of load in 'Brinell Hardness Test'
 8. State the selection of load in Rockwell Hardness Test'

For regular Rockwell Hardness using spherocone "Brile" Indenter
 $HR[\text{Scale}] = 100 \cdot h / 0.002$
 Where Scale is A, C, D and h is the depth penetrated in mm
 For regular Rockwell Hardness using a steel ball
 $HR[\text{Scale}] = 130 \cdot h / 0.002$

where Scale is B, E, F, G etc and h is in mm

[Space for Answers]

Q1 Ans Hardness of material is generally defined as

- resistance to the permanent indentation under static and dynamic load.

- Q2 Ans**
1. Brinell hardness test
 2. Rockwell hardness test
 3. Knock hardness test
 4. Vicker hardness test

Q3 Ans Both ball and diamond cone type of indenters are used in this test there scale are mls scale. A with indentor used for performing test on them Steel

- Q4 Ans**
1. Rockwell hardness testing
 2. Brinell hardness testing
 3. Knock hardness testing
 4. Vicker hardness testing

Q5 Ans Hardness is characteristics material that a fundamental physical property it is state the resistance to indentation determine by indentation

Q8 Ans It states measuring depth of indentation

XV	References / Suggestions for further Reading
1	https://www.youtube.com/watch?v=lx-vJ85sBA
2	https://www.youtube.com/watch?v=veysfhnHooc
3	https://www.youtube.com/watch?v=NlWVmp_q_XE
4	https://www.youtube.com/watch?v=RJXJpeh78IU
5	https://www.youtube.com/watch?v=G2JGNlIvNC4


XVI Assessment Scheme

Performance Indicators		Weightage
Process related (15 Marks)		60%
1 Handling of hardness tester		20
2 Mounting of specimen		20
3 Hardness testing		40%
4 Product related (10 Marks)		10
5 Specimen tested		10
6 Interpretation of result		10
7 Conclusions		10
7 Practical related questions		10
Total (25Marks)		100 %

Names of Student Team Members


- 1
- 2
- 3

Process Related(15)	Product Related(10)	Total (25)	Marks Obtained	Dated signature of Teacher



A Perform Peel Test to determine the Strength of adhesives.

<http://www.testing-instruments.com/blog/perform-peel-test-to-determine-the-strength-of-adhesives/>



(B) Geometry of the 180° peel test

IX Resources required

S. No.	Instrument / Components	Specification	Quantity	Remark
1	Digital Peel Tester	Load capacity: Up to 5 kg No of load cell: One Cross Travel: Up to 250 mm Speed: 300 mm/minute Direct display: Peak load Paint: Powder coated	01	
2	Peeling Strength Tester	Capacity Range: 0-200 N (30 N, 50 N and 100 N are optional) Accuracy: 1% of reading value Resolution: 0.01N Test Speed: 50, 100, 150, 200, 250, 300, 500 mm/min Specimen Width: ≤30 mm Stroke: 500 mm	01	

IX Resources required

- X Precautions (if any)
1. Use peel tester carefully
 2. Apply tapes on test plate properly

XI Procedure

1. Adhere the specimen to the testing plate.
2. Fold an end of the specimen to create a tab parallel to the plate.
3. Secure the end of the plate farthest away from the tab to the moving grip.
4. Secure the tab to the static grip.
5. Move the plate and begin peeling the tape at a 180 degree angle at the specified rate.
6. Record the average force required for peeling.

Or

1. Prepare at least 10 specimens according to the guidelines in the specification. A specimen consists of a flexible adhesive capable of folding back and peeling at a 180 degree angle as well as a substrate material to bond the adhesive to. The substrate object may be wood, textile, metal, or rubber. Samples must be conditioned according to the standard between preparation and testing.
2. Bond approximately six inches of the adhesive to the substrate material. Fold back the free end of the tape or sealant to a 180 degree angle.
3. Attach the free end of the substrate material to the vice grip on the testing machine's crosshead section. Keeping at least one inch of separation between the substrate material and the free end of the adhesive, secure the free part of the adhesive to the second vice grip.
4. Ensuring that the sample is in the plane of the vice grips, zero the materials testing machine. Move the crosshead at the specified rate until at least half of the bonded section has been peeled.
5. Record the average load. Repeat this test at least 10 times for each adhesive type.

XII Resources Used

S. No.	Instrument / Components	Specification	Quantity
1.	Digital Peel tester	load capacity S	1
2.	Peeling Strength tester	Capacity Range 0-200N	1
3.	Cello Phone (tape)	Adhesive tape	1/m group of 5

XIII Actual Procedure Followed

1. Adhere the specimen to the testing plate.
2. Fold one end of the specimen to create a tab parallel to the plate.
3. Secure the end of the plate from test away from the tab to the moving grip.

XIV Precautions Followed

1. Use peel tester carefully
2. Apply tapes on test place properly

XV Observations and Calculations

Name of tape	Load (N)	Thickness (t) mm	Width (b) mm	Avg Peel Strength N/mm ²

Calculation Peel Strength = Load / Area under Load

XVI Results

1. Adhesive strength of Cellophane is -----
2. Adhesive strength of duct tape is -----

XIX Practical Related Questions

Note: Below given are few sample questions for reference. Teachers must design more such questions so as to ensure the achievement of identified CO

1. List the uses of duct tape?
2. Name the five brands of cellophane tape in market
3. Name the five different commercial brands of tapes in the market
4. Define the term 'Peel Strength'
5. Name any five different adhesive tapes used in industrial applications with their specifications
6. Explain whether the process that makes adhesive tape sticky is physical or chemical?
7. Is the tape conductive?

[Space for Answers]

Hence I can used red tester to check adhesion strength of Cellophane

The no. of strength is to of the induction is
The impact of the no.

XVIII Conclusions & Recommendation**XVII Interpretation of results**

XX References / Suggestions for further Reading

1. <https://www.youtube.com/watch?v=wLRptWkbhjY>
2. https://www.youtube.com/watch?v=IwA_TGnjyUI
3. <https://www.youtube.com/watch?v=6SIswBN5YtI>
4. <https://www.youtube.com/watch?v=XQqsxcmXRya>
5. <https://www.youtube.com/watch?v=xMn0HqrTVi8>
6. <https://www.youtube.com/watch?v=kTRk42hzxl8>

Q1 Duct tapes is commonly used in situation that require a strong, flexible and very sticky tape.

Q6 The simple and that I can fit the question is that pressure sensitivity are strictly fine are exceptionally very high viscosity that also have some elastic.

XI Assessment Scheme

Performance indicators		Weightage
1	Preparation of experimental set up	40%
2	Mounting of tapes	10%
3	Testing of tapes	10%
	Product related (15 Marks)	20%
4	Prepared tape specimen	60%
5	Interpretation of result	30%
6	Conclusions	10%
7	Practical related questions	10%
	Total (25Marks)	100 %

Names of Student Team Members

- 1.
- 2.
- 3.

Marks Obtained		Dated signature of Teacher
Process Related(10)	Product Related(15)	Total (25)

X**Precautions (if any)**

1. Use protective equipment such as tongs or high temperature gloves when handling hot items, and beware of electric shock.

XI**Procedure**

1. Fill the beaker with water
2. Place the beaker on the hot plate and turn to 'High'. The water should be heated to just below boiling
3. Bend the nitinol wire to a desired shape
4. Place the nitinol wire in the hot water
5. The nitinol wire should immediately return to its original shape
6. Remove the nitinol wire from the beaker using the pliers and show it to the students
7. Repeat steps 3-6, trying different shapes and amounts of deformation
8. Repeat steps 3-6 with the steel wire

XII Resources Used

S. No.	Instrument/Components	Specification	Quantity
1	Shape memory alloy wire	min 10 mm	
2	Glass beaker	Suitable Size	
3	Heat Source	A power Source	
4	High Temperature Gloves / Tong	Suitable type	

XIII Actual Procedure Followed

1. Fill the beaker with water
2. Place the beaker on the hot plate and turn to 'High' (The water should be heated to just below boiling)
3. Bend the Nitinol wire in the hot water

XVII Interpretation of results

If we want to increase same ability to decrease we can adjust its property by heat treatment

XVI Results

1. Heated wire
2. Cooled wire

XVIII Conclusions & Recommendation

We can able high temp effect - over Electrical power source to turn a wire into a desired shape

If we want to increase same ability to decrease we can adjust its property by heat treatment

XIX Practical Related Questions

Note: Below given are a few sample questions for reference. Teachers must design more such questions so as to ensure the achievement of identified CO

1. State the difference between shape memory and super elasticity on a macroscopic level and on a microscopic level?
2. Justify The nitinol wire change shape, but not the steel wire?
3. State the uses you think of for materials that have this special behavior?
4. Explain the difference in super-elasticity and the shape memory effect. How are both achieved?

- 5 Name the forms of SMA have the same physical appearance?
- 6 State Practical applications for shape memory alloys
- 7 Explain the effect when a metal is heated above its transformation temperature?
How can this effect be reversed?
- 8 State the effect of the structure of a SMA during transition?

[Space for Answers]

2 Ans

Nitinol is also known as nickel, titanium and its alloy where, our steel is alloy of carbon and iron. Iron is a hard metal and the nickel and titanium Surface Compatte

3 Ans

Plastic ; more durability
Copper : Good electrical and thermal conductivity
Iron : Hard metal
Glass : transparent
Tungsten : High melting point
Steel : High corrosion resistance
Rubber : High elasticity

4 Ans

Super elastic material regains its original properties when force is removed elongate when stored

Shape memory alloy does not regain their original property naturally but they need heat

7 Ans when this alloy is in below transformation temp it undergoes low yield strength and when it deform easily into any new shape which it will retain if this alloy heated above its transformation temperature

IX Resources required

S. No.	Instrument /Components	Specification	Quantity	Remark
1	Laboratory box furnaces	1200°C	02	
2	Digital Rockwell hardness tester-Easy-to-use Electronics Console	Hi/Lo Tolerance Settings, Adjustable Time @ Load Average Test Group Results 2-9, Test Result Memory Capacity 5000 results, RS232 Output,- Average Range.	02	

X Precautions (if any)

1. For quenching, the sample should be immediately transferred from the furnace to the water/oil bath.
2. The quenching media should be agitated.
3. The specimen should be well grinded and polished before measuring hardness.
4. Hardness should be checked in cold state.

XI Procedure

1. Put all the samples in the furnace and heat it for the selected temperature.
2. Hold the samples in the furnace for given soaking period.
3. Select any two cooling medium for quenching.
4. Take out the samples one by one and immerse it in quenching mediums.
5. As sample gets cooled, its faces are ground and polished to get an even surface.
6. Check hardness and plot graph, if desired.

Selection of heat treatment conditions

	Heating temperature	Socking time	Quenching media
	880°C, 920°C, 960°C	1 hour	Water, Brine, Oil or Air

XII Resources used (with major specifications)

S. No.	Instrument /Components	Specification	Quantity
1.	laboratory box	1200°C	1
2.	Digital Rock well	Hi/Lo tolerance	1
3.	hardness-tester	Setting, adjust time	
4.	Easy-to-use		
5.	Electronics Console		

XIII Actual procedure followed

1. Select any two cooling medium for quenching.
2. Note reading.

XIV Precautions followed

The quenching media should be agitated.
Hardness should be checked in cold state.

XV Observations and Calculations

Table 1: Measurement of hardness from test

Sr. No	Specimen	Indentor Diameter(D) in mm	Total load(P) Kg-F	Diameter of Indentation(d) in mm			Average dia	RHN
				1	2	3		
1	Al	2.5	150	1.6	1.7	1.9	1.73	84.95
2	Cu	2.5	150	1.2	1.7	1.1	1.1	150
3	MS	2.5	150	0.8	0.7	0.76	0.76	9.22

Table 2: Measurement of effect of quenching on hardness

Material	Initial Hardness (RHB)	Hardness after quenching			
		Quenching Medium			
		Water	Brine	Oil	Air
Al	54.33	59.8	63	61.4	56.5
Cu	150	102	107	164.5	154.8

Calculations :

Calculate Hardness after quenching treatment:=

XVI Results

Quenching is best cooling medium after heat treated from above observation table it is conclude that oil is medium first water

The effect of different oil-quenching temperatures on the properties and structures of steel.

XVII Interpretation of results

Hardness is depend upon heating from temperature quenching medium material composition from observation table it proved that hardness no change with quenching medium.

XVIII Conclusions and Recommendations (if any)

$$\text{Al} = 54.95$$

$$\text{Cu} = 18.0$$

After quenching with oil

$$\text{Al} = 60.4$$

$$\text{Cu} = 164.5$$

XIX Practical Related Questions

Note: Below given are a few sample questions for reference. Teachers must design more such questions so as to ensure the achievement of identified CO.

1. State the importance of cooling rate?
2. Plot a graph of different hardness values in Rc scale for various heat treated low carbon steel specimen
3. Plot a graph 'Hardness vs. tempering temperature for constant tempering time of 1 hour'.
4. Plot a graph 'Hardness vs. tempering temperature for constant tempering time of 1/2 hour'

5. Plot a graph 'Hardness vs. tempering temperature for constant tempering time of 2 hours'
6. When austempering steel after the 10 minutes in the 400°C bath the specimen is removed from the bath and can be either quenched in water or allowed to air cool at room temperature. Will these two procedures produce different results? Explain
7. Discuss the relationship between heat treatment and the resulting hardness values obtained in this experiment
8. State the effect of water contamination affect the performance of quench oil?
9. State the effect of oxidation of oil on quench oil performance?
10. State bath agitation affect quenching?
11. State the effect of salt concentration in brine?
12. Some heat treated components develop cracks? Give reason
13. State the reason for stresses develop during quenching?
14. State distortion of quenched component due to?
15. Is there a way of calculating the required cooling rate for a given component?
16. Is there a simplified approach for guiding in the selection of proper quenchant?

[Space for Answers]

1Ans The hardness of material depend on the cooling state of material

The cooling state determine the property of material if we cool it fast will get other properties other than we want

2Ans After removal from brine dry salting is followed by peaking of sample
The effect of Salt Concentration in the brine has been in matter of contiguously with form

Q 9 Ans. Contamination of quench oil can make markedly affect shear performance surface of water include water cooled bracing fan, water oil

XX References / Suggestions for further Reading

- a. <https://www.wikihow.com/Harden-Steel>
- b. <https://www.youtube.com/watch?v=QQ051Zie8pk>
- c. https://www.youtube.com/watch?v=Gmjqkuc-n_IU
- d. <https://www.youtube.com/watch?v=U1patVgm8C0>
- e. <https://www.youtube.com/watch?v=U-DesKKNi9g>
- f. <https://www.youtube.com/watch?v=hw4Rl0uG7ok>
- g. <https://www.youtube.com/watch?v=gPKkgmDoEoU>
- h. <https://www.youtube.com/watch?v=bkxVLj3ezwA>
- i. <https://www.youtube.com/watch?v=ulfCxDsVTWo>

XXI Assessment Scheme

Performance indicators		Weightage
Process related (15 Marks)		60%
1	Hardening of specimen	20
2	Quenching of specimen	20
3	Hardness measurement of specimen	20
Product related (10 Marks)		40%
4	Hardened specimen	20
5	Quenched specimen	20
Total (25Marks)		100 %

Names of Student Team Members

1.
2.
3.

Marks Obtained	Dated signature of Teacher
Process Related(15) Product Related(10)	Total (25)